



**new construction  
water treatment  
drilling  
service**

## **What to do after we bleach your well.**

1. Recommend letting Bleach set in system for 12 hours, if possible. But at least 2 hours.

2A. If you have a Frost-Free Faucet. Turn on faucet by well and let run until bleach is purged

\*Make sure to remove water hose and let run open flow.

\*May need to put something under faucet to prevent the water from washing the dirt out.

2B. If you have a buried Valve. Hook up PVC to valve and purge system there. Run water until bleach is purged

2C. If you do not have above options, then run as much water throughout house as possible, until bleach is purged.

\*Making sure that the pump is not cycling.

\*\* Residual Bleach smell may remain.

\*\*The more bacteria in the well the more bleach smell you may notice.

## **What to do after we bleach your whole house.**

1. Run water to hot and cold faucets throughout the house until you smell bleach.

2. Let water sit in system for 24 hours.

3. Purge bleach from well first. Refer to purging well instructions above.

4. When bleach has been fully purged from well, run water throughout house until bleach is gone.

\* Hot water will take longer.

5. Turn water heater back on.

\* Electric water heater – Turn on Breaker in breaker panel

\*Gas water heater – Turn knob from pilot to desired heat setting.

6. If you have a Water Softener – Take water softener out of bypass

**www.JBWaterWell.com**  
**1135 S Choctaw Rd · Luther, OK · 73054**  
**405.388.2246**